	N TYPE MUFFLER (M1 TY						
CODE	Dio 110 EBJ- (FNO, JF58-1000001 ~ 1099999) /2BJ- (FNO, JF58-1100001 ~) 548-1437310						
•Thank you for purchasing Kitaco pr		nstruction before	installing				
			nistaning.				
ATTENTION (MUST	-						
•We are not responsible for viola	0	ccidents caused	l by				
assembling mistake and improp							
 This product is designed and m 	ade exclusive for application n	nodels, do not i	use other				
models.	a far according and acting (at an acialty				
 Please ask authorized mechanic shep if you do not understand the 			at specially				
shop if you do not understand the Refer to the manufacturer servi	•	5.					
 Bolts and nuts may get loosen I 		not to loopon	any holto and				
nuts before driving.	by engine vibration. Wake sure		any boits and				
	Do not touch the engine parts	1					
This sheet is intended for the person who has basic	(cylinder, crankcase, muffler,	FLA	MABLES				
knowledge for maintenance.	engine oil, etc) right after engine operation. Make sure to start		nmable high gasoline d during operation.				
Do not operate if you do not have skill and knowledge.	the installation after the engine parts are completly cool.	<u>(,)</u>	a aanng operationi				
∧ Do not modify the	The shape is different						
way which is not listed	from genuine one,						
or it will cause damage and trouble.	please be careful of burning until get used to						
	it.						
ACKING LIST *() is 1set qty.							
	ME	CODE	QTY				
GURE NA			()				
1 SILENCER ASSY (SUS/GPR)		559-0500000	(× 1)				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY		541-1437490	(× 1)				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY		541-1437490 541-1437480	(× 1) (× 1)				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY 4 SILENCER BAND	φ 112 110/2 5Tmm	541-1437490 541-1437480 0900-995-10110	(× 1) (× 1) × 2				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY 4 SILENCER BAND 5 SILENCER BAND RUBBER	110/2.5Tmm	541-1437490 541-1437480	(× 1) (× 1)				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY 4 SILENCER BAND 5 SILENCER BAND RUBBER		541-1437490 541-1437480 0900-995-10110 0900-999-11110	(× 1) (× 1) × 2 × 2				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY 4 SILENCER BAND 5 SILENCER BAND RUBBER 6 FLANGE CAP BOLT 7 WASHER 8 U NUT	110/2.5Tmm M8 × 35	541-1437490 541-1437480 0900-995-10110 0900-999-11110 080-05 63035	$(\times 1)$ $(\times 1)$ $\times 2$ $\times 2$ $\times 2$ $\times 2$				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY 4 SILENCER BAND 5 SILENCER BAND RUBBER 6 FLANGE CAP BOLT 7 WASHER 8 U NUT 9 SPRING (SUS)	110/2.5Tmm M8 × 35 8 × 18 × T 1.2mm 8mm 8 × 57	541-1437490 541-1437480 0900-995-10110 0900-999-11110 080-0563035 090-0601082 001-0540008 542-9998000	(× 1) (× 1) × 2 × 2 × 2 × 2 × 2 × 2 (× 2)				
1 SILENCER ASSY (SUS/GPR) 2 EXHAUST PIPE ASSY 3 SILENCER STAY 4 SILENCER BAND 5 SILENCER BAND RUBBER 6 FLANGE CAP BOLT 7 WASHER 8 U NUT	110/2.5Tmm M8 × 35 8 × 18 × T 1.2mm 8mm	541-1437490 541-1437480 0900-995-10110 0900-999-11110 080-0563035 090-0601082 001-0540008	(× 1) (× 1) × 2 × 2 × 2 × 2 × 2 × 2				

OPTION PARTS (SOLD SEPARATELY) *() is 1set qty.						
FIGURE		NAME	CODE	QTY		
OP1	MUFFLER GASKET	(XH- 02)	963-100000 2	(× 2)		
-	LIQUID GASKET	(KC -027)	0900-969-00010	× 1		


instruction sheet is just a reference, please refer to the manufacturer service manual.) cally, reuse genuine parts if it is unattached. If there is a hard degradation like a blem, fatigue and wear

on the reuse parts, please change to new ones. Il Kitaco muffler temporarily with installing attached parts. (Refer to the illustration.)

ly liquid gasket (KC-027) that sold separately to connecting point of silencer and exhaust pipe not to leak aust. Do not start engine until liquid gasket is dry. (around 1 hour)

ommend to change muffler gasket to new one (sold separately).

en with specified torque while adjusting each parts. Make sure not to leak exhaust.



NTION!

iding a lot, surface of the product (especially exhaust pipe) might change its color, but it's not unusual. want to remove burning, please use specified chemicals that sold commercially.

- ting engine with oil or dirt, it changes color or burned (only that place). Please wipe it with degreaser before ng engine.

- ot leave this product with water. It might cause of tarnish or rust.
- HOW TO TAKE CARE
- •Rust and corrosion caused by surface oxidation is caused by exhaust high heat. Genuine muffler is the same. This is characteristic, which cannot avoid. However, it only occurs to surface. Applying heat resist silicone wax to delav tarnish.



3-8-13 NAGATA, HIGASHI-OSAKA,

171013 Y-N