



K·TOUR

REBEL250/500

EASY INSTALLATION!

FOR REBEL 250/500!
JUST COUPLER-ON TO GET POWER!
USB POWER SUPPLY NEWLY
RELEASED!



To prepare battery supply for cell phone, and etc.! Just insert between coupler to get battery! No wiring mods required!

USB POWER SUPPLY KIT

CODE	PRICE
80-757-18600	¥4,400
<ul style="list-style-type: none"> ● COUPLER-ON (USB POWER SUPPLY INSTALLED ON HANDLE BAR) ● EXCLUSIVE HARNESS (17~19) INCLUDED ● FROM : 2P OPTION COUPLER (17~19) INSIDE THE HEADLIGHT CASE METER / SWITCH WIRE (20~) HARNESS NOT INCLUDED ● INTERFACE : USB X 2 PORT ● INPUT / OUTPUT : DC12V / DC5V : MAX 2A (when using 1 port) ● ACC ⊕ ACCESSORY / GND ⊖ : EARTH ● DRIP-PROOF ● STAY : STEEL WITH BLACK ● LED BUILT-IN (BLUE) 	
APPLICATION REBEL250 (MC49)、REBEL500 (PC60)	

- ※ 12V VEHICLE ONLY.
- ※ Not completely waterproof. Do not use it when washing vehicle or rain. Use rubber cap when not using.
- ※ Condensation might happen inside the cap according to the weather. Do not install this near the engine and remove the dew with air duster / vacuum if happened.
- ※ Not for the large current products such as amplifiers & compressors



LED LIGHT-ON IMAGE



THIS TIME, "BRAKE LEVER (L)" ARE NEWLY RELEASED!

K·PIT

REPLACEMENT LEVER
NEWLY RELEASED!!



REPLACEMENT BRAKE LEVER FOR JAPANESE 4 MAKERS.
※ SOME LEVERS HAVE DIFFERENT SHAPE & FINISH COMPARED TO GENUINE ONES.

★ REFER TO KITACO WEBSITE FOR DETAILS



BRAKE LEVER (R) HR-25
PRICE : ¥1,700
CODE : 70-525-61250

HL-26

HONDA BRAKE LEVER (L)

TYPE	COLOR	CODE	GENUINE NUMBER	APPLICATION	PRICE
HL-26	BLACK	70-525-62260	53178-KOW-N01	ADV150 (KF38)	¥1,900

ELECTRIC RELATED PARTS

SEROW 250, YZF-R25, YZF-R3, MT-25, MT-03 etc.

START ENGINE WHILE USING
SIDE STAND!!



Engine starts while using side stand.

SIDE STAND SWITCH CANCELLER (type-D)

CODE	PRICE
676-9000930	¥400
● SOLD EACH	
APPLICATION YZF-R25 (1WD/B0E/B3P/2WD/BS8/B6P)、MT-25 (B04/B1E/B4W)、YZF-R3 (B02/BR5/B7P)、MT-03 (B05/BOB/B6W)、GEAR (10B)、TRICKER (5XT/B8C)、SEROW 250 (3C5/1YB/B1H/B7C)、XT250X (5C1)、BOLT-R SPECK (B33) etc. ※ Japanese models only	

- ※ Using side stand while engine is on, is very dangerous.
- ※ Starting engine with side stand out leads to falling down.
- ※ Drive after making sure that side stand is folded inside.